



SCHEMA DI MONTAGGIO - ASSEMBLY SCHEDULE

COD. **58.0493.00**

REV. **00** DEL. **20/07/2012** TEC-LOG **G.D.**

Descrizione **FORD S-MAX**

Fig. 1






-  Fissare il gommino in dotazione sulla staffa già presente sotto la vettura;
-  Fix the gum-ring in equipment on the bracket already present under the car;
-  Installer le petit bouchon en caoutchouc en dotation sur l'étrier déjà présent sous la voiture;
-  Fijar el anillo de goma en dotación con el estribo presente bajo el coche;
-  Installieren Sie den Gummiring des Montagekits auf die schon unter dem Auto vorhandene Schelle;



Fig. 2






-  Tagliare la nicchia sul lato destro simmetricamente a quella originale!
-  Incise the niche on the right side symmetrically to the original ones!
-  Entailler la niche à droite en symétrie à la niche originale!
-  Entallar el agujero en el lado derecho en simetria con el original!
-  Schneiden Sie die Niche auf der rechten Seite symmetrisch zu der Originalen ein!

Fig. 3

-  Installare lo scarico completo come in figura 3!
-  Install the silencers as shown in picture 3!
-  Installer l'échappement complète comme dans l'image 3!
-  Instalar el escape como en el imagen 3!
-  Installieren Sie die gesamte Anlage wie in Abbildung 3!

